

Envy Pumps

Blank Shoes Instructions

Sanding

Bottom rim

A shoe has a small rim around the bottom and around the bottom of the heel. It protrudes slightly. You can choose to sand it off or leave it as-is.

If you choose to sand it off use a 200-grit sandpaper or a 200-grit emery board (preferred). We recommend the 200-grit because it can give you faster results, but it will leave small scratches . To smooth out the scratches you will need the 400-grit sandpaper (no emery board). As an alternative you may use only a 400-grit sandpaper to sand off the rim, but it will take a bit longer.

Sole

The sole needs to be sanded using a 400-grit paper.

Outer

The rest of the shoe has a smooth and slightly glossy finish. You can buff it using a nail buffing block in order to prepare it for priming and painting.

Primer

Use any acrylic primer.

Paint

Use any acrylic crafting paint.

Varnish

Use a varnish of your preference: glossy, satin, or matte.